Assembly Instructions for the Endy250 Rotary

Thank you for purchasing one of my Rotary Jigs, a few simple steps to assemble this one ;-)

Remove the nut and washer from the aluminium extrusion. Push the extrusion into the slot on the front of the headstock. This is intentionally a very tight fit. Give it a good wiggle – it will go!! Insert the bolt and washer through the hole on the rear of the headstock into the extrusion. Tighten the bolt. Torque setting: Somewhere between 'Finger Tight' and 'Reasonably Tight' The axle with the nut can now be fitted to the headstock. See the Quick Start for usage instructions.